EXHIBIT R

Setting Up A New PIN

Updated 3 months ago

What are PINs?

PINs are the four-digit sequences used to arm and disarm your system, as well as to lock and unlock the Smart Lock. When setting up your system, you will be prompted to create a Master PIN.

However, you have the option to create additional Custom and Duress PINs.

When you set up Custom PINs, you'll be able to delegate access to your location, without allowing an individual to make changes to your SimpliSafe system. You'll also be able to see which PIN was used to arm or disarm your system in the timeline on the Mobile App or Web app.

Duress PINs can be used in emergency situations to immediately dispatch police to your location.

Please note that PINs are different from your Safe Word. Your Safe Word will be needed to make changes to your monitoring subscriptions and to verify or

eedback

cancel an alarm event when you're on the phone with our team of experts.

Setting up PINs

There are three types of PINs in our latest SimpliSafe: Master, Custom, and Duress.

The Smart Lock uses the exact same PINs as the Keypad. There are two ways to change or add PINs.

1. The Keypad:

- 1. Push the Menu button on the Keypad
- 2. Enter your Master PIN
- 3. Select PINs
- 4. Follow the onscreen prompts to create and save each new PIN you'd like to add





2. The SimpliSafe mobile app: 1. Open the menu by clicking on the three horizontal lines at the top of the screen 2. Choose Location Profile 3. Select PINs at the bottom of the screen 4. Select Add Custom PIN 5. Follow the onscreen prompts to create and save each new PIN you'd like to add 6. In the future, you can change the name of a PIN, the PIN itself, or delete it by clicking on the PIN. 0:00 / 0:12 **PIN Types** PIN Use Typ

е	
Mas	Allows disarming your
	Allows disarming your
ter	system. The Master PIN is
PIN	also required in order to
	access the Keypad's menu.
Cus	Custom PINs are similar to
tom	the Master PIN, but cannot
PIN	access the menu to change
	system settings. Give these to
	friends and family to let
	them disarm your system.
	Naming them allows you to
	keep track of who is
	disarming your system. These
	can be added and deleted as
	needed.
Dur	Emergency PIN used to
ess	instantly notify emergency
PIN	responders that you are
	under duress. When this PIN
	is entered on the Keypad,
	we'll dispatch the police
	immediately (and disarm the
	system to fool intruders).